



CALIBRATION PROCEDURE

1. POWER DOWN UNIT
2. REMOVE ANY SPOUT THAT MAYBE IN THE ACTIVATOR
3. PRESS AND HOLD BOTH P2 + P4 (CALIBRATION)
4. POWER UP SPYLITE WHEN LIGHTS START TO FLASH RELEASE BUTTONS
5. THE LIGHTS WILL STOP FLASHING + THE P2 WILL LIGHT UP
6. INSERT SPOUT # 15 AND PRESS P2 BUTTON
7. KEEP SPOUT 15 FULLY INSERTED TILL P3 LIGHTS UP
8. REMOVE SPOUT FROM ACTIVATOR
9. PRESS P3 TO CONFIRM CALIBRATION, THEN POWER DOWN



MASTER CLEAR PROCEDURE

1. POWER DOWN UNIT
2. REMOVE ANY SPOUT THAT MAYBE IN THE ACTIVATOR
3. PRESS AND HOLD BOTH P1 + P3 (MASTER CLEAR)
4. POWER UP THE UNIT
5. WHEN THE PORTION LIGHTS GO OUT RELEASE THE BUTTONS
6. MASTER CLEAR IS COMPLETE
7. POWER DOWN

N.B. UNIT MUST BE RECALIBRATED AFTER A MASTER CLEAR.

