



## DRAFT CONTROL OPTIONS

GEN: General Options		Station #	
	<b>Features</b>	1-255	Station #
+1	Sales Open		
+2	Enable Automatic Portions		<b>Choice of Language</b>
+4	Enable Price Level Schedule		
+8	Enable Price List	+0	French
+64	Enable Event Schedule	+1	English
+128	Enable Owner Protected Program (OPP)	+2	Spanish
	<b>Scanner port</b>	+3	Portuguese
+16	Activates ECR Scanner port		
GEN2: General Options 2		SCAN: Scanner/ ECR Interface	
	<b>Inter-PLU Delay</b>		<b>PLU Options</b>
+0	No delay	+1	Send 12 digit PLU (099999 XXXYY)
+32	500ms delay	+0	YX (Spout Y, Portion X)
+64	1sec. Delay	+2	1YX (Spout Y, Portion )
+96	1,5 sec. Delay	+4	10YX (Spout Y, Portion )
		+6	100YX (Spout Y, Portion )
		+8	Use PLU Stored in memory
+128	Phase X CRC CCITT-8408		<b>When the ECR Scanner Port is activated</b>
		+16	Activates the check digit required by certain ECRs
	<b>COMM: Communication Options</b>	+32	Adds a prefix byte before the PLU
	<b>Reporting</b>	+64	Removes the line feed (0x0D)
+0	6 extra line feeds at the end of report	+128	Removes the carriage return (0x0A)
+1	9 extra line feeds at the end of report		
+2	12 extra line feeds at the end of report		<b>PREFIX1: Prefix (for SCAN + 32) *</b>
+3	15 extra line feeds at the end of report	+2	CRS3000 Scanner Interface
+4	Will not print out reports while in the RUN mode	+65	Uniwell Scanner interface
			<b>PREFIX2: Prefix (for SCAN + 32) *</b>
	<b>Parity</b>	+2	CRS3000 Scanner Interface
+0	No parity	+65	Uniwell Scanner interface
+16	Odd parity		
+48	Even parity		
			<b>PRICELV: Price Level Schedule *</b>
	<b>Baud rate</b>	HRS	<b>PLV default and days</b>
		99	<b>DISABLE</b>
+0	1200 Baud rate	00-23	Set Price Level 1
+64	2400 Baud rate	00-23	Set Price Level 2
+8	4800 Baud rate	00-23	Set Price Level 3
+128	9600 Baud rate	00-23	Set Price Level 4
+192	19200 Baud rate	00-23	Set Price Level 5
+72	28800 Baud rate	00-23	Set Price Level 6
+136	38400 Baud rate	00-23	Set Price Level 7
+200	57600 Baud rate	00-23	Set Price Level 8
	<b>PRICELVL: Price Levels</b>		<b>EVNT SC.: Event Schedule *</b>
1-8	Activate that number of price levels	HRS	
		99	<b>DISABLE</b>
		00-23	Close
		00-23	Open
		00-23	Print X2 Report
		00-23	Print Z2 Report
		00-23	Reboot Station

\* FUNCTION MUST HAVE BEEN ENABLED\*